









1 - 0 - 6 - 7	Connessione scheda di potenza/ Connection avec fiche de puissance / in der Hilfstromkreis / connexion con carte de potencia
1 - 1 3 - 3	Pedali inversione marcia / Pedals / Pédales / Pedal / Pedales
2 - 2 4 - 4	Contatti manipolatore / Joystick / Joystick / Joystick / Joystick /
6 - 6	Pulsante start/ Start/ Start/ Start
7 - 7	Pulsante stop / Stop / Stop / Stop / Stop


8 - 8 9 - 9	Microinterruttori ripari anti infortunistici
5 - 5	Lampada (opzione) / Lamp/ Lampe/ Lampe / Claro
LD1	Led start / Led start / Led start / Led start /
LD2	Led marcia dx / Right gear Led / Led marche droite / Rechte Led Gang / Derecho arranque led
LD3	Led marcia sx / Left gear led / Led marche gauche/ Linke Led Gang / Izquierdo arranque led



F1	Fusibile 1° TF- Fuse- Fusible- Sicherung- Fusible
F2	Fusibile 2° TF Fuse- Fusible- Sicherung- Fusible
TF	Trasformatore - Transformer - Transformateur - Transformador

K17M - K18M	Contattore— Contactor— Contacteur— Kontaktor— Contactor
LDO	Led presenza tensione 2° TF— Led—Led—Led—Led
M	Motore 1 velocità— 1 Speed engine— Moteur 1 vit—Motor 1G— Motor 1 V.





VAR	CIRCUITO POTENZA -POWER PLATE- FICHE DE PUISSANCE – LEISTUNGSKREIS – CARTE DE POTENCIA	TAB.5																																																																						
	<table><tr><td></td><td>INTERRUTTORE</td><td>START BUTTON</td><td>BOUTON START</td><td></td></tr><tr><td>QS1</td><td>MICROINTERRUTTORE</td><td>MICROSWITCH</td><td>MICROINTERRUPTUR</td><td>MICROINTERRUPTORE</td></tr><tr><td>SQ2</td><td>MICROINTERRUTTORE</td><td>MICROSWITCH</td><td>MICROINTERRUPTUR</td><td>MICROINTERRUPTORE</td></tr><tr><td>SB1</td><td>PULSANTE EMERGENZA</td><td>EMERGENCY STOP BUTTON</td><td>ARRET D'URGENCE</td><td>PARO STOP</td></tr><tr><td>SB2,SB3</td><td>JOYSTICK</td><td>JOYSTICK</td><td>JOYSTICK</td><td>JOYSTICK</td></tr><tr><td>SA0703.0A</td><td>SCHEDA ELETTRONICA</td><td>ELECTRCONIC CARD</td><td>FICHE ELECTRIQUE</td><td>CARTA ELECTRONICA</td></tr><tr><td>SA0703.0B</td><td>SCHEDA ELETTRONICA</td><td>ELECTRONIC CARD</td><td>FICHE ELECTRONIQUE</td><td>CARTA ELECTRONICA</td></tr><tr><td>FU1 6X32</td><td>FUSIBILE</td><td>FUSE</td><td>FUSIBLE</td><td>FUSIBLE</td></tr><tr><td>FU2 5X20</td><td>FUSIBILE</td><td>FUSE</td><td>FUSIBLE</td><td>FUSIBLE</td></tr><tr><td>FU3 5X20</td><td>FUSIBILE</td><td>FUSE</td><td>FUSIBLE</td><td>FUSIBLE</td></tr><tr><td>FU4 5X20</td><td>FUSIBILE</td><td>FUSE</td><td>FUSIBLE</td><td>FUSIBLE</td></tr><tr><td>FU5 5X20</td><td>FUSIBILE</td><td>FUSE</td><td>FUSIBLE</td><td>FUSIBLE</td></tr><tr><td>CF1</td><td>INVERTER</td><td>INVERTER</td><td>INVERTER</td><td>INVERTER</td></tr><tr><td></td><td></td><td></td><td></td><td></td></tr></table>		INTERRUTTORE	START BUTTON	BOUTON START		QS1	MICROINTERRUTTORE	MICROSWITCH	MICROINTERRUPTUR	MICROINTERRUPTORE	SQ2	MICROINTERRUTTORE	MICROSWITCH	MICROINTERRUPTUR	MICROINTERRUPTORE	SB1	PULSANTE EMERGENZA	EMERGENCY STOP BUTTON	ARRET D'URGENCE	PARO STOP	SB2,SB3	JOYSTICK	JOYSTICK	JOYSTICK	JOYSTICK	SA0703.0A	SCHEDA ELETTRONICA	ELECTRCONIC CARD	FICHE ELECTRIQUE	CARTA ELECTRONICA	SA0703.0B	SCHEDA ELETTRONICA	ELECTRONIC CARD	FICHE ELECTRONIQUE	CARTA ELECTRONICA	FU1 6X32	FUSIBILE	FUSE	FUSIBLE	FUSIBLE	FU2 5X20	FUSIBILE	FUSE	FUSIBLE	FUSIBLE	FU3 5X20	FUSIBILE	FUSE	FUSIBLE	FUSIBLE	FU4 5X20	FUSIBILE	FUSE	FUSIBLE	FUSIBLE	FU5 5X20	FUSIBILE	FUSE	FUSIBLE	FUSIBLE	CF1	INVERTER	INVERTER	INVERTER	INVERTER						
	INTERRUTTORE	START BUTTON	BOUTON START																																																																					
QS1	MICROINTERRUTTORE	MICROSWITCH	MICROINTERRUPTUR	MICROINTERRUPTORE																																																																				
SQ2	MICROINTERRUTTORE	MICROSWITCH	MICROINTERRUPTUR	MICROINTERRUPTORE																																																																				
SB1	PULSANTE EMERGENZA	EMERGENCY STOP BUTTON	ARRET D'URGENCE	PARO STOP																																																																				
SB2,SB3	JOYSTICK	JOYSTICK	JOYSTICK	JOYSTICK																																																																				
SA0703.0A	SCHEDA ELETTRONICA	ELECTRCONIC CARD	FICHE ELECTRIQUE	CARTA ELECTRONICA																																																																				
SA0703.0B	SCHEDA ELETTRONICA	ELECTRONIC CARD	FICHE ELECTRONIQUE	CARTA ELECTRONICA																																																																				
FU1 6X32	FUSIBILE	FUSE	FUSIBLE	FUSIBLE																																																																				
FU2 5X20	FUSIBILE	FUSE	FUSIBLE	FUSIBLE																																																																				
FU3 5X20	FUSIBILE	FUSE	FUSIBLE	FUSIBLE																																																																				
FU4 5X20	FUSIBILE	FUSE	FUSIBLE	FUSIBLE																																																																				
FU5 5X20	FUSIBILE	FUSE	FUSIBLE	FUSIBLE																																																																				
CF1	INVERTER	INVERTER	INVERTER	INVERTER																																																																				